



Flavone Assay Kit

ARG83417 Flavone Assay Kit can be used to measure Flavone in tissue extracts and other biological fluids.

Catalog number: ARG83417

Package: 96 wells

For research use only. Not for use in diagnostic procedures.

TABLE OF CONTENTS

SECTION	Page
INTRODUCTION	3
PRINCIPLE OF THE ASSAY	3
MATERIALS PROVIDED & STORAGE INFORMATION.....	3
MATERIALS REQUIRED BUT NOT PROVIDED.....	4
TECHNICAL HINTS AND PRECAUTIONS	4
SAMPLE COLLECTION & STORAGE INFORMATION	4
REAGENT PREPARATION	5
ASSAY PROCEDURE	5
CALCULATION OF RESULTS.....	6
EXAMPLE OF TYPICAL RESULT.....	7

MANUFACTURED BY:

Arigo Biolaboratories Corporation

Address: 9F.-7, No. 12, Taiyuan 2nd St., Zhubei City,

Hsinchu County 302082, Taiwan

Tel: +886-3-6221320

Fax: +886-3-5530266

Email: info@arigobio.com

INTRODUCTION

Flavones occur in a wide variety of fruits, vegetables, and beverages. In their native forms, they are found as both O- and C-glycosides, with O-glycosides being more common and usually better absorbed.

PRINCIPLE OF THE ASSAY

The Flavone Assay Kit can measure Flavone in tissue extracts and other biological fluids. The increase in absorbance at 420 nm is directly proportional to reactants of the reaction between substrate and Flavone.

MATERIALS PROVIDED & STORAGE INFORMATION

Component	Quantity	Storage
Microplate	1 X 96-well plate	
Standard	1 vial (lyophilized)	4°C
Assay Buffer	4 X 30 ml (ready to use)	4°C
Reaction Buffer	15 ml (ready to use)	4°C
Reagent Dye A	5 ml (ready to use)	4°C
Reagent Dye B	3 ml (ready to use)	4°C

MATERIALS REQUIRED BUT NOT PROVIDED

- Microplate reader capable of measuring absorbance at 420 nm
- Pipettes and pipette tips
- Deionized or distilled water

TECHNICAL HINTS AND PRECAUTIONS

- Wear protective gloves, clothing, eye, and face protection especially while handling blood or body fluid samples.
- Store all components store at 4°C.
- Briefly spin down the reagents before use.
- It is highly recommended that the standards and samples be assayed in at least duplicates.
- Change pipette tips between the addition of different reagent or samples.

SAMPLE COLLECTION & STORAGE INFORMATION

The sample collection and storage conditions listed below are intended as general guidelines. Sample stability has not been evaluated.

Tissue - Weigh out 0.1 g tissue, homogenize with 1 ml Assay Buffer, then transfer it to the microcentrifuge tubes; incubate at boiling water bath for 30 mins; centrifuged at 10,000g for 10 minutes, take the supernatant into a new centrifuge tube for detection.

*Note: liquid samples can detect directly.

REAGENT PREPARATION

- **Standard:** Add **1 ml** of **distilled water** to dissolve standard, then add 0.2 ml stock into 0.8 ml Reaction Buffer. The concentration will be **2 $\mu\text{mol/ml}$** . Perform 2-fold serial dilution of the top standards to make the standard curve.

ASSAY PROCEDURE

Standards and samples should be assayed in at least duplicates.

1. Sample wells: Add **20 μl** of **Sample** into Sample wells.
2. Standard wells: Add **20 μl** of **Standard** into Standard wells.
3. Add **100 μl** of **Assay Buffer** to each wells.
4. Add **50 μl** of **Reagent Dye A** to each wells.
5. Add **30 μl** of **Reagent Dye B** to each wells.
6. Mix well. Incubate at **RT** for **30 min**.
7. Mix well. Read the OD at **420nm**.

Reagent	Sample	Standard	Blank
Sample	20 μl	-	-
Standard	-	20 μl	-
Assay Buffer	-		20 μl
Reagent Buffer	100 μl	100 μl	100 μl
Reagent Dye A	50 μl	50 μl	50 μl
Reagent Dye B	30 μl	30 μl	30 μl
Mix well. Incubate at RT for 30 min			

CALCULATION OF RESULTS

1. Calculate the average absorbance values for each set of samples, standard and blank.

2. Calculation:

A. Definition:

C_{Standard}: the standard concentration, 2 µmol/ml = 0.002 mmol /ml;

W: the weight of sample, g;

V_{Sample}: the volume of reaction sample, 20 µl = 0.02 ml;

V_{standard}: the volume of standard, 20 µl = 0.2 ml;

V_{assay}: the volume of Assay Buffer, 1000 µl = 1 ml.

B. Formula:

a). According to the weight of sample

Flavone (mmol/g) =

$$\begin{aligned} & [(C_{\text{Standard}} \times V_{\text{standard}}) \times (OD_{\text{Sample}} - OD_{\text{blank}})] / [(OD_{\text{Standard}} - OD_{\text{Blank}}) \times (W \times \\ & V_{\text{Sample}} / V_{\text{assay}})] \\ & = 0.002 \times (OD_{\text{Sample}} - OD_{\text{blank}}) / [(OD_{\text{Standard}} - OD_{\text{Blank}}) \times W] \end{aligned}$$

b). According to the volume of sample

Flavone (mmol/ml) =

$$\begin{aligned} & [(C_{\text{Standard}} \times V_{\text{standard}}) \times (OD_{\text{Sample}} - OD_{\text{blank}})] / [(OD_{\text{Standard}} - OD_{\text{Blank}}) \times V_{\text{Sample}}] \\ & = 0.002 \times (OD_{\text{Sample}} - OD_{\text{blank}}) / (OD_{\text{Standard}} - OD_{\text{Blank}}) \end{aligned}$$

Flavone Assay Kit ARG83417

3. Detection range:

The detection range is from 0.02 $\mu\text{mol/mL}$ - 2 $\mu\text{mol/mL}$.

4. If the samples have been diluted, the calculated activity must be further converted by the appropriate dilution factor according to the sample preparation procedure as described above.

EXAMPLE OF TYPICAL RESULT

The following data is for demonstration only and cannot be used in place of data generations at the time of assay. Please note this data is for demonstration only and serially diluted standards are necessary for this kit.

